



PROCOM<sup>®</sup>

## OPERATING INSTRUCTIONS

### COP-Plus

(ANSI CODE 51, 50, 51N, 51G, 50N, 50G, 50BF, 79, 74TC)



Installation Guide

# Index

1. Introduction
2. Protection, Supervision Salient features
3. Out Put Contact
4. Protection
5. User Interface
6. Setting Procedure / Menus
7. Setting Procedure Parameter Mode
8. External Alarm Contact
9. Reset – Auto / Manual
10. Model Selection Chart
11. Flow Chart
12. Communication
13. Connection Diagram
14. Technical Specification
15. Dimensional Details

## 1.0 Introduction

- The COP Plus Series of Feeder Protection Relays are Designed Using Numerical Technology (Discrete Fast Fourier Transformation.) Reliable & Accurate Tripping is Ensured by Deploying Digital Technique Using DSP. High Sampling Rate of 2000 Sample/Sec Ensures Actual Reproduction of Waveform.
- User Friendly HMI Eases Configuration & Operating Procedure of Relay
- User Programmable Digital Output Provides Flexibility in Selecting Alarm Contact.
- In Addition to Default USB Part one Optional RS-485 Port is also Provided.

## 2.0 Protection, Supervision Salient Features

- 128x64 Pixel Graphical /display
- Event Recording
- Fault Date Recording
- RTC Stamp on Fault & Event
- Three/Five Digital Input
- Site Selectable 1A/5A CT Secondary Current
- Wide Auxiliary Supply(20 To 300 VDC/50-300VAC)
- Display in Primary/Secondary Values
- Wide Setting Range With Fine Setting Steps
- Front USB Port
- RS-485 communication Port with MODBUS protocol
- Self Supervision

## 3.0 Output Contact

Cop Plus had upto seven NO Contact. One is reserved for tripping function. Three are programmable for alarm function.

Trip (NO/NC Contact)

- Alarm 1 (NO Contact)
- Alarm 2 (NO Contact)
- Relay ON Contact (NO Contact)
- Alarm 3 (NO Contact)
- Alarm 4 (NO Contact)
- Charging Contact (NO/NC Contact)

## 4.0 Protection

- |                                   |                                      |
|-----------------------------------|--------------------------------------|
| ■ Over Current Protection         | ■ High Ground Fault Protection       |
| ■ Short Port Current Protection   | ■ Trip Current Supervision           |
| ■ Earth Fault Protection          | ■ Circuit Breaker Failure Protection |
| ■ High set Earth Fault Protection | ■ Multiple Shot Auto Re-closer       |
| ■ Ground Fault Protection         | ■ Lock Out                           |

- Tripping Characteristics
  - Definite Time - DEFT
  - Inverse Time - Extremely Inverse
  - Inverse Time - Very Inverse
  - Inverse Time - Normal Inverse 0.6
  - Inverse Time - Normal Inverse 1.3
  - Inverse Time - Normal Inverse 3.0
- Selective Earth/ground Fault Blocking In Case of single phase voltage supplied on all three phases.
- All the protections can be programmed to be individually or collectively blocked by external input
- Remote Trip Input
- Remote Reset input

## 5.0 User Interface



### 5.1 LCD Display








Graphical back-lit LCD Display is provided for parameter and setting display and for easy viewing of measurement, setting, fault and event records, date and time, error message. Back-lit is automatically turned ON when any tripping occurs on particular equipment.

### 5.2 Touch Keys

The function of relay is controlled by the following keys. Back Switch, Next Switch, Up Switch, Down Switch, Enter key, Reset Key and Test Key which are provided on the front plate. Front plate with diagram and keys marked will be good

Cop plus has a very sophisticated HMI build into it. These keys play different role under different function of HMI

Switch Symbol	Switch Function	Description
	Back Switch and Next Switch	To enter Edit/View Mode the Back Switch and Next Switch are pressed together.
	Back Switch	The Left Arrow Key are used to go backward both when doing the settings and while viewing the settings.

	Next Switch	The Right Arrow key are used to go forward both when doing the settings and while viewing the settings.
	Up Switch	The Up Arrow Key is used to increment the value of parameters in setting mode.
	Down switch	The Down Arrow Key is used to increment the value of parameters in setting mode.
	Enter Switch	Pressing enter key will take the HMI in the sub menu of displayed Menu.
	Test Switch	Test Key is for testing the unit, if this function is enabled in the settings.
	Reset Switch	Reset key is used to reset the fault annunciations. RESET key is used to discard while doing the settings and abort to main menu.
	BC Switch	CB key is used to close the Circuit Breaker ( Available in Auto re-closure model only)

Note: At the time of setting if changes are not carried within 20s then the display will reset itself and return to the main menu.

## Front Panel and Control :

S.no	LED's	Description
1	I >	This led indicates an over current.
2	I >>	This led indicates a short circuit.
3	Ie >	This led indicates an Earth Fault at lower set.
4	Ie >>	This led indicates an Earth Fault at higher set.
5	CBFP	This led indicates a circuit breaker fault.
6	Lock Out	This led indicated that the Auto Re-closure attempts were not able to clear the faults.
7	TCS	This led indicates a Trip Circuit Failure.
8	Trip	This led indicates a fault occurrence.

## LCD Display :

Back-lit LCD display 128 \* 64 by 2 lines is provided for Viewing and Editing the parameter, Viewing and Editing the annunciation, Fault records, Event records, Date and Time and also for password changing.

## 6.0 Setting Procedure / Menus


COP Plus has provision to program the operating parameters. It is user / site configurable. User can view all parameters, fault history, events, adjust clock, reset password and also edit the parameter.




Following is the sequential procedure to edit. View all the menus and submenus.

Press "Back Switch  & Next Switch  simultaneously."  
The LCD shall display, "Edit Parameter"

### A. Edit Parameter

Edit Parameter is password protected.

To enter 'Edit Parameter' mode, press enter key   
The LCD shall display, "Enter Password".

Enter Password. The default password is 123. Press enter  key .For any change in value, press Up switch  and Down switch 

For next parameter, press Next Switch  .We can also view the previous parameter, by pressing Back Switch 

## **B. Edit Annunciations**

After Edit Parameter, press Up Switch ⬆

The LCD shall display "Edit Annunciation".

Cat\_COP-Plus-Ver 1.0 01.01.2015

Edit Annunciation is password protected.

Edit Annunciation can modify / viewed by pressing enter key ⬇

## **C. Edit Block Function**

After Edit Annunciation, press Up Switch ⬆

The LCD shall display "Edit Block Function".

Edit Block Function is password protected.

Edit Annunciation can modify / viewed by pressing enter key ⬇

## **D. View Parameter**

After Edit Block Function, press Up Switch ⬆

The LCD shall display "View Parameter".

View Parameter can be viewed by pressing enter key ⬇

## **E. View Annunciation**

After View Parameter, press Up Switch ⬆

The LCD shall display "View Annunciation".

View Annunciation can be viewed by pressing enter key ⬇

## **F. Display History**

After View Annunciation, press Up Switch ⬆

The LCD shall display "Display History".

Trip record / history can be viewed by pressing enter key ⬇

COP-Plus keep a record of last 32 tripping with date and time stamp.

Tripping records are updated on first in first out basis.

## **F. Display Event**

After Display History, press Up Switch ⬆

The LCD shall display "Display Event".

Trip record / history can be viewed by pressing enter key ⬇

COP-Plus keep a record of last 32 events with date and time stamp.

Event records are updated on first in first out basis.


## **F. Adjust Clock**

After Display Event, press Up Switch ⬆


The LCD shall display "Adjust Clock".


Time and Date can be modified by pressing enter key ⬇

## F. Reset Password

After Adjust Clock, press Up Switch 

The LCD shall display "Reset Password".

Password can be modified by pressing enter key 


COP-Plus will request for the present password, after feeding correct password change password will be requested and the password will be replaced by new password on pressing Up Switch 


### Default Display:


After Power ON or when the RESET is done, it will show the following display :





This window will flash momentarily showing the following display. Then the control will go automatically to next window which is shown below :



This will display the current in all phases in terms of percentage if the display set to display value in secondary. After 10 sec the display will automatically scroll to next display window or press Enter key  can be used to manually switch to next window.




This will display the earth fault current in terms of percentage. By pressing enter key , the display will show as :




This will the display the time and date.


## 6.1 Parameter Setting




This is default window showing the actual Primary Load Current as per CT ratio.

Press the Back Switch , and the Next Switch  simultaneously, the display will show as follows:



In this mode, we can edit the different parameter setting as per our convenience. To enter this mode, press enter key 



Enter password by using Up  Switch and  the Down Switch

If the password is wrong, the display will be :






Wrong  
Password

After displaying this, it will return to the main menu.



If the password is correct, the display will be :


I >In I / In  
0.50

By using Up Switch  and the Down Switch  , the desired value can be set. The value can be set from 0.10 to 9.99 in steps of 0.01 I/In.



Press the Next Switch  to view the next parameter, display will show as follows:


I > Def Time  
0.30

By using Up Switch  and the Down Switch  , the desired value can be set. The value can be set from 0.03 to 150.0 in steps of 0.01 sec.



Press the Next Switch  to view the next parameter, display will show as follows:


I >Time  
Multiple  
0.30

By using Up Switch  and the Down Switch  , the desired value can be set. The value can be set from 0.10 to 2.50 in steps of 0.01.



Press the Next Switch  to view the next parameter, display will show as follows:


I >  
Characteristic  
DEFT

By using Up Switch  and the Down Switch  , the desired characteristic can be set. It can be set as DEFT / Extremely Inv / Very Inverse / Normal Inv 0.6 / Normal Inv 1.3 / Normal Inv 3.0



Press the Next Switch  to view the next parameter, display will show as follows:


I >>in I/In  
4.0

By using Up Switch  and the Down Switch  , the desired value can be set. The value can be set from 0.2 to 30.0 in steps of 0.1 I/In.



Press the Next Switch  to view the next parameter, display will show as follows:


I >> Def Time  
0.03

By using Up Switch  and the Down Switch  ,the desired value can be set. The value can be set from 0.03 to 20.0 in steps of 0.01 sec.



Press the Next Switch  to view the next parameter, display will show as follows:


EF Measure Type  
51G EXT Earth CT

By using Up Switch  and the Down Switch , the desired value can be set. The type can be set as either 51G EXT Earth CT or 51N Internal Cal.



Press the Next Switch  to view the next parameter, display will show as follows:


le >In I / In  
0.20

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 0.10 to 10.0 in steps of 0.01 I/In.



Press the Next Switch  to view the next parameter, display will show as follows:


le > Def Time  
0.30

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 0.03 to 150.0 in steps of 0.01 sec.



Press the Next Switch  to view the next parameter, display will show as follows:


le >Time  
Multiple  
0.30

By using Up Switch  and the Down Switch , the desired The value can be set from 0.1 to 1.50 in steps of 0.01



Press the Next Switch  to view the next parameter, display will show as follows:

le >  
Characteristic  
Deft



By using Up Switch  and the Down Switch , the desired can be set. It can be set from DEFT / Extremely Inv / Very Inverse / Normal Inv 0.6 / Normal Inverse 1.3 / Normal Inv 3.0


Press the Next Switch  to view the next parameter, display will show as follows:

le >>in I/In  
0.5



By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 0.2 to 10.0 in steps of 0.1 I/In.


le >> Def time  
0.3

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 0.2 to 20.0 in steps of 0.1 I/In.



Press the Next Switch  to view the next parameter, display will show as follows:


CT Ratio  
1

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 1 to 9999 in steps of 1.



Press the Next Switch  to view the next parameter, display will show as follows:


CT  
Secondary  
5A

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set either 5 Amp or 1 Amp.



Press the Next Switch  to view the next parameter, display will show as follows:


Trip Ckt Sup  
Disabled

By using Up Switch  and the Down Switch , the desired type can be set. It can be set either as Disabled or Enabled.



Press the Next Switch  to view the next parameter, display will show as follows:


CB Failure  
Ann.  
Disabled

By using Up Switch  and the Down Switch , the desired type can be set. It can be set either as Disabled or Enabled.



Press the Next Switch  to view the next parameter, display will show as follows:


CB F Dealay  
0.50

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 0.05 to 2.00 in steps of 0.01



Press the Next Switch  to view the next parameter, display will show as follows:


Single  
Phasing  
Disabled

By using Up Switch  and the Down Switch , the desired type can be set. It can be set either as Disabled or Enabled.



Press the Next Switch  to view the next parameter, display will show as follows:


Test Function  
Disabled

By using Up Switch  and the Down Switch , the desired type can be set. It can be set either as Disabled or Enabled.



Press the Next Switch  to view the next parameter, display will show as follows:


No. of AR Shots  
0

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 0 to 4 in steps of 1



Press the Next Switch  to view the next parameter, display will show as follows:


AR Shot 1 DT  
2.0

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 0.5 to 250 in steps of 0.1



Press the Next Switch  to view the next parameter, display will show as follows:


AR Shot 2 DT  
2.0

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 0.5 to 250 in steps of 0.1



Press the Next Switch  to view the next parameter, display will show as follows:


AR Shot 3 DT  
2.0

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 0.5 to 250 in steps of 0.1



Press the Next Switch  to view the next parameter, display will show as follows:


AR Shot 4 DT  
2.0

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 0.5 to 250 in steps of 0.1



Press the Next Switch  to view the next parameter, display will show as follows:


Reclaim Time  
15

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 10 to 500 in steps of 1.



Press the Next Switch  to view the next parameter, display will show as follows:


Close Pulse  
Time 1.0

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 0.1 to 20.0 in steps of 0.1



Press the Next Switch  to view the next parameter, display will show as follows:


Reset Delay  
0.5

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 0.1 to 1.0 in steps of 0.1 sec.



Press the Next Switch  to view the next parameter, display will show as follows:


Disp Auto  
Scroll  
Auto Scroll  
On

By using Up Switch  and the Down Switch , the desired type can be set. The type can be set either as Auto Scroll On or Auto Scroll Off.



Press the Next Switch  to view the next parameter, display will show as follows:


Dis in Pri/Sec  
Secondary

By using Up Switch  and the Down Switch , the desired type can be set. The type can be set either as Primary / Secondary.



Press the Next Switch  to view the next parameter, display will show as follows:


Trip Reset  
Auto

By using Up Switch  and the Down Switch , the desired type can be set. The type can be set either as Auto / Manual.



Press the Next Switch  to view the next parameter, display will show as follows:


Device Id  
1

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set from 1 to 247.



Press the Next Switch  to view the next parameter, display will show as follows:

Baud Rate  
9600

By using Up Switch  and the Down Switch , the desired value can be set. The value can be set as 1200/2400/4800/9600/19200.

Press the Next Switch  to view the next parameter, display will show as follows:

Parity None

By using Up Switch  and the Down Switch , the desired parity can be set. It can be set as Even, Odd, None.

Press the Next Switch (▶) to view the next parameter, display will show as follows:

No of Stop  
Bits  
1

By using Up Switch (▲) and the Down Switch (▼), the desired value can be set. The value can be set as 1 or 2.

Press the Next Switch (▶) to go to the main menu.

## 6.2 To edit annunciation parameter :

After Edit Parameter, press Up Switch (▲), the display will show as follows:

Edit  
Annunciation

In this mode, we can edit the different parameter setting as per our convenience. To enter this mode, press enter key (↵). The display will show as:

Enter  
password  
0

Enter password by using Up Switch (▲) and Down Switch (▼). Press the enter key (↵), the display will show as follows:

If the password is wrong, the display will be :

Wrong  
Password

After displaying this, it will return to the main menu.

If the password is correct, the display will be :

Announce I >  
On A1  
Contact

By using Up Switch (▲) and the Down Switch (▼), the desired contact can be set. It can be set as A1 / A2 / A3 / A4 / Not Announced

Press the Next Switch (▶) to view the next parameter, display will show as follows: .


Announce I >>  
On A1  
Contact

By using Up Switch (▲) and the Down Switch (▼), the desired contact can be set. It can be set as A1 / A2 / A3 / A4 / Not Announced.



Press the Next Switch (▶) to view the next parameter, display will show as follows:


Announce Ie >  
On A1  
Contact

By using Up Switch (▲) and the Down Switch (▼), the desired contact can be set. It can be set as A1 / A2 / A3 / A4 / Not Announced.



Press the Next Switch  to view the next parameter, display will show as follows:


Ann. CB Failure  
On A2 Contact

By using Up Switch  and the Down Switch , the desired contact can be set. It can be set as A1 / A2 / A3 / A4 / Not Announced.



Press the Next Switch  to view the next parameter, display will show as follows:

Ann. Look Out  
On A3 Contact

By using Up Switch  and the Down Switch , the desired contact can be set. It can be set as A1 / A2 / A3 / A4 / Not Announced.

Press the Next Switch  to view the next parameter, display will show as follows:

Ann. Trip Ckt  
On A4 Contact


By using Up Switch  and the Down Switch , the desired contact can be set. It can be set as A1 / A2 / A3 / A4 / Not Announced.

Press the Next Switch  to go the main menu.


### 6.3 To Edit Block Function:

After Edit Annunciation , press Up Switch , the display will show as follows:

Edit Block  
Function

In this mode, we can block the different current area as per our convenience. To enter this mode, press enter key 

Enter password by using Up Switch  and Down Switch 



Press the enter key , the display will show as follows:


Wrong  
Password

After displaying this, it will return to the main menu.

If the password is correct, the display will be :


Block 1>  
Disabled

By using Up Switch  and the Down Switch  , the desired over current can be blocked. It can be set as enabled or disabled.



Press the Next Switch  to view the next parameter, display will show as follows:


Block 1>>  
Disabled

By using Up Switch  and the Down Switch  , the desired short circuit current can be blocked. It can be set as enabled or disabled.



Press the Next Switch  to view the next parameter, display will show as follows:

Block I E >  
Disabled

By using Up Switch  and the Down Switch  , the desired Earth fault lower set values can be blocked. It can be set as enabled or disabled.


Press the Next Switch  to view the next parameter, display will show as follows:

Block I E >>  
Disabled


By using Up Switch  and the Down Switch  , the desired Earth fault lower set values can be blocked. It can be set as enabled or disabled.

Press the Next Switch  to go to the main menu.


## 6.5 To View Parameter

After Edit Block Function, press Up  Switch to View Parameter. In this mode, we can only view the readings of the parameter, no change in value is allowed here.


## 6.6 To View Annunciation

After View Parameter, press Up Switch  to View Annunciation. In this mode, we can only view the readings of the annunciation, no change in value is allowed here.

## 6.7 To View Display History:


After Edit Block Function, press Up Switch  ,the display will show as follows:

Display  
History


To view the record of last faults occurred, press enter key  .




The Faults which occurred previously are displayed. Some of the Examples are:



Whenever the fault occurred, an fault is generated and will be shown in display history block with respective time and date. This is the random time and date for the example purpose.





Whenever the fault occurred, an fault is generated and will be shown in display history block with respective time and date. This is the random time and date for the example purpose.




Whenever the fault occurred, an fault is generated and will be shown in display history block with respective time and date. This is the random time and date

## 6.6 To View Display Event:


After Display History, press Up Switch , the display will show as follows:

To view the list of events occurred, press enter key , the display will show as


The events which occurred previously are displayed. Some of the Examples are:



Whenever the password is changed, an event is generated and will be shown in display event block with respective time and date. This is the random time and date for the example purpose.




Whenever the time and date is changed, an event is generated and will be shown in display event block with respective time and date. This is the random time and date for the example purpose.




Whenever the value of parameter is changed, an event is generated and will be shown in display event block with respective time and date. This is the random time and date for the example purpose

## 6.7 To View Adjust Clock:

After Display Event, press Up Switch , the display will show as follows:



To change the time and date, press enter key . The display will show as:



This is the random time and date for the example purpose. The values can be change by using up arrow key  $\uparrow$  and down arrow key  $\downarrow$  .To switch from seconds to minutes or minutes to hours, press enter key, the cursor will move according to that and once time is changed, the date page is displayed as:




This is the random time and date for the example purpose. The values can be change by using up arrow key  $\uparrow$  and down arrow key  $\downarrow$  . To switch from seconds to minutes or minutes to hours, press enter  $\rightarrow$  key, the cursor will move according to that.

## 6.8 To Reset Password


After Adjust Clock, press Next Switch  $\rightarrow$  , the display will show as follows:




To Reset the password, press enter key  $\rightarrow$  , display will show as :




Enter the current password by using the up arrow key  $\uparrow$  and down arrow key  $\downarrow$  . The display will show as :



Enter the new password which you want to set by using the up arrow key  $\uparrow$  and down arrow key  $\downarrow$  , press enter key  $\rightarrow$  , the display will show as :



Press up arrow key  $\uparrow$  to update the password else presdown arrow key  $\downarrow$  to escape from the page. The display will show as :



It means password is updated.

## 7.0 Setting Procedure Parameter Mode

Display	Explanation of parameter	Factory setting	Setting Range	Setting step
I > in I/In	Desired over current value in % of the rated current	0.50	0.1-10.00 I/In	0.01I/In
I > Def Time	Definite time delay in seconds, will be valid only when definite time characteristic is selected	0.30 Sec	0.10 – 150 Sec	0.01 Sec

Display	Explanation of parameter	Factory setting	Setting Range	Setting step
I > Time Multiplier	Inverse time multiplier, will be valid only when Inverse time characteristic is selected	0.3	0.10- 2.50	0.01
I > Characteristic	Time delay characteristic for Over current	DEFT	DEFT, Extreme inverse, Very Inverse, Normal Inverse 0.6, Normal inverse 1.3, Normal Inverse 3.0	
I > > in I/In	Desired short circuit values in % of the rated current.	4.0	0.2-30.0 I/In	0.1 I/In
I >> Def Time	Definite time delay in seconds, will be valid only when definite time characteristic is selected	0.03	0.03 – 20 Sec	0.01 Sec
EF measure type	Earth fault measurement method	51G ext earth CT	51G ext earth CT 51N internal cal.	
I e> in I/In	Desired Earth fault value in % of the rated current	0.20	0.10-10.0 I/In	0.01 I/In
I e> Def Time	Definite time delay in seconds, will be valid only when definite time characteristic is selected	0.30 Sec	0.03 – 150 Sec	0.01 Sec
I e> Time Multiplier	Inverse time multiplier, will be valid only when Inverse time characteristic is selected	0.3	0.1 - 1.50	0.01

I e>	Time delay characteristic for Earth fault current	normal inverse 3.0	DEFT, Extreme Inverse, Very Inverse, Normal Inverse 0.6, Normal inverse 1.3, Normal Inverse 3.0	
I e> > in I/In	Desired earth fault high set value in % of the rated current	0.5	0.2-10.0 I/In	0.1 I/In
I e>> Def Time	Time delay setting for earth fault high set	0.03	0.02 – 20 Sec	0.01 Sec
CT Ratio	Ratio of current transformer, Rated CT Primary current / Rated CT Secondary current	1	1-9999	1
CT-Secondary	Rated CT secondary current	5A	5A, 1A	
Trip Ckt Sup.	Trip Circuit supervision	Disabled	Enabled/disabled	
CB Failure Ann	Circuit Breaker Failure Protection	Disabled	Enabled/disabled	
CB F Delay	Delay time of CB	0.50	0.05-2.00	0.01
Single Phasing	Single Phasing Enable/Disable	Disabled	Enabled/disabled	
Test Function	Test Function Enable/Disable	Disabled	Enabled/disabled	
No. of AR Shots	No. of short for Auto reclosure	0	1-4	1
AR Shot 1 DT	Dead Time of AR short 1	2.0	0.5-250	0.1

AR Shot 2 DT	Dead Time of AR short 2	2.0	0.5-250	0.1
AR Shot 3 DT	Dead Time of AR short 3	2.0	0.5-250	0.1
AR Shot 4 DT	Dead Time of AR short 4	2.0	0.5-250	0.1
Reclaim Time	Time of Reclaim	15	10-500	1
Close Pulse Time	Time of Close Pulse	1.0	0.1-20.0	0.1
Reset Delay	Delay time for resetting the trip contact, after fault clearance.	0.5	0.1-1.0Sec	0.1 sec.
Disp AutoScroll	Measurement display auto scroll or manual scroll selection	Auto Scroll On	Auto Scroll On / Auto Scroll off	
Dis I in Pri/Sec	Selection of Current display in primary values or secondary values	Secondary	Primary/Secondary	
Trip Reset	Reset type for tripped LED indication	Auto	Auto / Manual	
Device ID	Device Identification Number	5	1-247	1
Baud Rate	Communication Baud Rate	9600	1200, 2400, 4800, 9600, 9200	
Parity	Parity Bit	None	Even, Odd, None	
No. of Stop Bits	No of stop bit	1	1-2	1

**\* Available only in model with auto-reclosure**

## 8.0 External Alarm Contact

1.0 Alarm Contact 1,2, 3 & 4 can be programmed / activated on different protection functions

Protection Function	Protection Symbol	Activated Alarm, default setting	Remark
Announce I >	I >	1	Alarm 1 activated on I >
Announce I >>	I >>	1	Alarm 1 activated on I >>
Announce I E>	Ie >	1	Alarm 1 activated on Ie >
Announce IE >>	Ie >>	1	Alarm 1 activated on Ie >>
Ann CB Failure	CBFP	2	Alarm 2 activated on CB
Ann Lock Out	LR	3	Alarm 3 activated on Lock out
Ann Trip Ckt.	TCS	4	Alarm 4 activated on trip circuit

## 9.0 Reset – Auto / Manual

User can programme COP-Plus either as auto reset or manual reset relay.


- Auto Reset : The trip contact & Indication will reset automatically after clearance of fault and expiry of reset delay.
- Manual Reset : The trip contact will reset automatically after clearance of fault and expiry of reset delay. Indication will reset after pressing the reset button.

## 10.0 Model Selection Chart

<b>PROTECTION</b>	<b>ANSI Code</b>	<b>COP+I</b>	<b>COP+1E</b>	<b>COP+IEG</b>	<b>COP+IK</b>	<b>COP+IEK</b>	<b>COP+IEGK</b>
IDMT Over Current Protection	51	■	■	■	■	■	■
Short Circuit Protection	50	■	■	■	■	■	■
Earth Fault Protection (Seperate CT)	51N			■			■
Earth Fault Protection Calculated	51G		■	■			■
High Set Earth Fault Protection(Seperate CT)	50N		■	■		■	■
High Set Earth Fault Protection(Calculated)	50G			■			■
Circuit Breaker Failure Protection	50BF	■	■	■	■	■	■
Auto Reclosure (Optional)	79				■	■	■
Trip Circuit Protection(Optional)	74TC	■	■	■	■	■	■
Front USB Part		■	■	■	■	■	■
RS-485 Communication Port(Optional)		■	■	■	■	■	■
Digital Input(Optional)		3	3	3	5	5	5
Digital Output		6	6	6	7	7	7


## 11.0 Flow chart

### Flow Chart - To Edit Parameter & To Edit Annunciation







# Flow Chart - To View Parameter & To View Annunciation



## Flow Chart - To Display History




## Flow Chart - To Display Event




Note : Event 1 To Events 32 Can Be Viewed Respectively

## Flow Chart - To Adjust Clock




## Flow Chart - To Reset password



## 12.0 Communication


The word communication, as the word symbolise itself, it is basically the communication of COP with PC via RS-232 or RS-485 protocol to know the values of data stored or list of events or faults records. We can also send the values of parameter or reset it or send the default values as per the application made. The software provide us great facilities to view all the readings or allow us to do changes very conveniently and it is very secure also.

Whenever the application is open, it requires login information for the security purpose. The display will be :



The screenshot shows a 'Login' dialog box with a purple title bar and a red close button. On the left is a circular logo with 'P' and 'M' in white on a blue background. The main area is titled 'COP+' and contains two input fields: 'User Name' with the text 'admin' and 'Password' with '\*\*\*\*\*'. At the bottom are 'OK' and 'Cancel' buttons.

By entering the user name and password, click OK then the new screen is displayed as :



The screenshot shows a 'Comport Configuration' dialog box with a purple title bar and standard window controls. The main area has a cyan header 'Serial Configuration' and the instruction 'Configure the parameter for the serial port.'. Below is a 'Parameters' section with five rows, each with a label and a dropdown menu:

Parameter	Value
Communication Port	COM15
Baud Rate(Bits Per Second)	9600
Data Bits	8
Parity	None
Stop Bits	One

An 'Ok' button is located at the bottom right of the dialog box.

Whenever the device is connected to the PC, a comport is generated, check the device manager for the port name, enter the Communication Port ,Baud Rate, Data Bits, Parity, Stop Bits and then press OK. The display will show as:



In this main form, we can select the model via select model, the display will be :



COP+

Cop+Model name  
COP+IEG-K.TCSC

Default Read Bin File Read Data Instantaneous Save File Password 123 Send Clear Close

Cop Parameters

l> in lfn	0.50	<input type="checkbox"/> Disable	AR Shot 3 DT	2.0	<input type="checkbox"/> Disable
l> Def Time	2.00	<input type="checkbox"/> Disable	AR Shot 4 DT	2.0	<input type="checkbox"/> Disable
l> Time Multipl	0.30	<input type="checkbox"/> Disable	Reclaim Time	15	<input type="checkbox"/> Disable
l> Characterist	DEFT	<input type="checkbox"/> Disable	Close Pulse Time	1.0	<input type="checkbox"/> Disable
d>> in lfn	4.0	<input type="checkbox"/> Disable	Reset Delay	0.5	<input type="checkbox"/> Disable
d>> Def Time	0.03	<input type="checkbox"/> Disable	Disp Auto Scroll	Auto Scroll Off	<input type="checkbox"/> Disable
EF Measure Type	51N Internal Cal	<input type="checkbox"/> Disable	Dis in Pri/Sec	Primary	<input type="checkbox"/> Disable
le> in lfn	0.20	<input type="checkbox"/> Disable	Trip Reset	Auto	<input type="checkbox"/> Disable
le> Def Time	0.30	<input type="checkbox"/> Disable	Device Id	1	<input type="checkbox"/> Disable
le> Time Multipl	0.30	<input type="checkbox"/> Disable	Baud Rate	9600	<input type="checkbox"/> Disable
le> Characterist	Normal Inv 3.0	<input type="checkbox"/> Disable	Parity	ODD	<input type="checkbox"/> Disable
le>> in lfn	0.5	<input type="checkbox"/> Disable	No. of Stop Bits	2	<input type="checkbox"/> Disable
le>> Def Time	0.03	<input type="checkbox"/> Disable	Announce l>	On A1 Contact	<input type="checkbox"/> Disable
CT Ratio	1	<input type="checkbox"/> Disable	Announce d>>	On A1 Contact	<input type="checkbox"/> Disable
CT Secondary	5 AMP	<input type="checkbox"/> Disable	Announce IE>	On A1 Contact	<input type="checkbox"/> Disable
Trip Ckt Sup	Disabled	<input type="checkbox"/> Disable	Announce IE>>	On A1 Contact	<input type="checkbox"/> Disable
CB Failure Ann	Disabled	<input type="checkbox"/> Disable	Ann CB Failure	On A2 Contact	<input type="checkbox"/> Disable
CBF Delay	0.50	<input type="checkbox"/> Disable	Ann Lock Out	On A3 Contact	<input type="checkbox"/> Disable
Single Phasing	Enabled	<input type="checkbox"/> Disable	Ann Trip Ckt	On A4 Contact	<input type="checkbox"/> Disable
Test Function	Disabled	<input type="checkbox"/> Disable	Block l>	Disabled	<input type="checkbox"/> Disable
No. AR Shots	0	<input type="checkbox"/> Disable	Block d>>	Disabled	<input type="checkbox"/> Disable
AR Shot 1 DT	2.0	<input type="checkbox"/> Disable	Block IE>	Disabled	<input type="checkbox"/> Disable
AR Shot 2 DT	2.0	<input type="checkbox"/> Disable	Block IE>>	Disabled	<input type="checkbox"/> Disable

By pressing the show read button, all the values stored in meter will be displayed. The save button is used to save all the readings.

We can also change the values and press send button to pass the values into the COP. By pressing Clear button, we can clear all the values in text boxes and drop down list. By pressing Close button, the form will be closed.

In the main form, by clicking the event login menu strip the display will be:



By clicking Fault Record, the faults generated will be displayed in the form as :

**Fault Selection**

1

**Fault**

Type	9	ly	0.000823592
CT Ratio	1	lb	0.001568765
CT - 5A-1A	5	le	0.001121491
Time	16:36:43	lr	0.0004930035
Date	13-12-2014		

By clicking the Event record, the list of events generated will be displayed on the form as :

**Show Events Record Instantaneous**

1				2			
Event no. 1	3	13-12-2014	15:53:34	Event No. 17			
Event No. 2				Event No. 18			
Event No. 3				Event No. 19			
Event No. 4				Event No. 20			
Event No. 5				Event No. 21			
Event No. 6				Event No. 22			
Event No. 7				Event No. 23			
Event No. 8				Event No. 24			
Event No. 9				Event No. 25			
Event No. 10				Event No. 26			
Event No. 11				Event No. 27			
Event No. 12				Event No. 28			
Event No. 13				Event No. 29			
Event No. 14				Event No. 30			
Event No. 15				Event No. 31			
Event No. 16				Event No. 32			

By clicking the read data, the values will be displayed on the form as :

Read Data Instantaneous

Save File

Clear

Close

Read Data


Current R Phase 0.001057277

Current Neutral 0.0002387758

Current Y Phase 0.0009896548

Current B Phase 0.002050675

### 13.0 Connection Diagram / Terminal arrangement






It is our endeavour to constantly upgrade our products, hence specifications are subject to change without any notice.

In case of Digital input, particular block is activated marked as DZ, depending upon the condition either trip contact is activated or relay contact is activated.


#### **14.0 Technical specification**

Frequency Range	40-70 Hz
Rated Current	1A /5A
Current withstand	10 times rated current
Measurement Accuracy	
• Voltage & Current	± 2%
• Frequency	± 0. 05 Hz.
Surge 1.2/50Usec	2.5KV
Auxiliary Voltage	20-300VDC & 50-300VAC
Contact Rating	230 VAC, 5A
Cut out Dimensions	190mm X 114mm
Depth	104mm


## 15.0 Dimensional Details :




Top View




Isometric View




Front View



Rear View



Side View



Cut Out Size



---

MRM *PROCOM*<sup>®</sup> Pvt. Ltd.  
Plot No. 20-21, Industrial Estate  
Sector-59 (II), HUDA, Faridabad-121004, Haryana  
Phone: 0129-4700400 (10 Lines), E-mail : [info@mrmprocom.com](mailto:info@mrmprocom.com)  
Website : [www.mrmprocom.com](http://www.mrmprocom.com)